

AQUA CHOICE SPORT B

Technical Data Sheet



CLEANCHOICE SPORT B Flex Clean

Description

CLEANCHOICE SPORT B FLEX CLEAN is used for intensive cleaning every time before a permanent coating is applied e.g. AQUA CHOICE SPORT B FLEX, or before full maintenance, e.g. with BRILLIANCE EVERCLEAR, and is ideal for smooth or structured PVC, CV, linoleum, rubber and PUR/epoxy-coated flooring and on artificial and natural stone floors.

Certificates / approvals



Giscode: GG20
ATFA: Compliant
NWFA: Compliant
MFMA: Compliant

Specifications

Components: Water, solvent, according MSDS
Clarity: Colorless
Scent: Lemon
Body: Light liquid
Texture: Water-like
Density: 8.43 lb/gal
Packaging: 33.8 us fl oz
Sheen: N/A
Coverage: 2000 sf/gal
Stability: Do not freeze
Levelling: N/A
Defoaming: N/A
Dry Time: <1/2 hr.
Cure Time: N/A
Chemical Resist: N/A
Shelf Life: 2 years unopened
Flash Point: N/A

For further details please refer to MSDS.

Basic cleaning

Cleaning before further treatment processes either with AQUA CHOICE SPORT B FLEX or BRILLIANCE EVERCLEAR:

Remove any loose dirt with a vacuum cleaner, broom or mop. Depending on where it is used, mix CLEANCHOICE SPORT B FLEX CLEAN with water in a ratio of 1:5 (private buildings) to 1:3 (commercial buildings). The product can be applied in a mix of 1:1 or even pure on care films and factory finishes that are difficult to remove.

Apply the cleaning solutions evenly on the floor and after approx. 20 minutes clean the surface completely using a monodisc machine with a BERGERTOOL SUPERPAD or BERGERTOOL ELASTICBRUSH EXTREME attached. Do not allow the cleaning solution and any loose dirt to dry on the floor. Mop up the loosened dirt with a wet vacuum cleaner or the BERGERTOOL APPLICATOR ELASTICPLUS and a mop.

Then carry out the neutralisation wet grinding process with lukewarm clean water using the monodisc machine with a BERGERTOOL ABRANET ACE or BERGERTOOL ABRANOPP AN ATTACHED. After wet grinding, completely remove all neutralisation dirt and dry the flooring for further processing either with AQUA CHOICE SPORT B FLEX or BRILLIANCE EVERCLEAR.

Final cleaning

Cleaning without further treatment (direct use):

Remove any loose dirt with a vacuum cleaner, broom or mop. Depending on where it is used, mix CLEANCHOICE SPORT B FLEX CLEAN with water in a ratio of 1:5 to 1:10.

Apply the cleaning solutions evenly on the floor and after approx. 10 minutes, clean the surface completely using a monodisc machine with a BERGERTOOL SUPERPAD or BERGERTOOL ELASTICBRUSH EXTREME attached.

Mop up the loosened dirt with a wet vacuum cleaner or the BERGERTOOL APPLICATOR ELASTICPLUS and a mop, and then wipe with lukewarm clean water and allow the floor to dry.

Special information

USE CLEANCHOICE SPORT B FLEX CLEAN on sections of the floor and do not allow to dry. Check the material and colour resistance on inconspicuous test areas. Avoid contact with sensitive surfaces made of wood, metal, painted surfaces or similar. All residues must be removed and the surface must be completely dry before general maintenance or application of the permanent coating.

Usage

Final cleaning (MV 1:5-1:10 with water):
approx. 25-12 ml/m² or 40-85 m²/L (2000 sf/gal) of the product

Basic cleaning (MV 1:3-1:5 with water):
approx. 40-25 ml/m² or 25-40 m²/L of the product

(Pure): approx. 125 ml/m² or 8 m²/L

Active ingredients

Anionic and non-ionic surfactants (< 5%), solvents (< 5%) and perfume (Citral, Limonene)

pH-value (conc.): approx. 10

Storage / transport

Ensure cool, dry and frost proof conditions during transport and storage; it can be stored in the unopened original packaging for at least 24 months. Keep away from children.

Description of first aid measures

If medical advice is needed, have product container or label at hand.

AQUACHOICE SPORT B^T

Technical Data Sheet



24-hour emergency number in side USA: +1 872 5888271

General information

In all cases of doubt, or when symptoms persist, seek medical advice. In case of unconsciousness give nothing by mouth, place in recovery position and seek medical advice.

In case of inhalation

Remove casualty to fresh air and keep warm and at rest. In case of irregular breathing or respiratory arrest provide artificial respiration.

Following skin contact

Take off immediately all contaminated clothing. After contact with skin, wash immediately with plenty of water and soap. Do not use solvents or thinners.

After eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Seek medical advice immediately.

Following ingestion

If swallowed, rinse mouth with water (only if the person is conscious). Seek medical advice immediately. Keep victim calm. Do NOT induce vomiting.

Most important symptoms and effects, both acute and delayed

In all cases of doubt, or when symptoms persist, seek medical advice.

Indication of any immediate medical attention and special treatment needed

First Aid, decontamination, treatment of symptoms.

Manufacturer's Recommendations

This Technical Data Sheet is based on extensive research and wide-ranging experience and is meant to assist you. Restrictive information and precautions have not been avoided in order to reduce risk of fault. Technical Data Sheets do not contain all applications or events that could occur with different species of wood, installation, techniques and finishing. Therefore, you cannot be released from the obligation to contact the manufacturer in cases of doubt, to make your own tests on site and to be critically attentive during the job process. The contents of this data sheet are not legally binding and do not establish any contractual legal relationship. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. This information is subject to change without further notice. Please read the instructions carefully before processing this product. This Berger-Seidle product must be

processed by a qualified person for parquet laying, for whom this manual is intended. The activities shall be carried out in accordance with the rules of the craft, the state of the art and the

applicable standards and regulations of the country in which the product is used (USA/CAN = NWFA // AUS = ATFA). The specifications of DIN 18356 "Parquet and wood paving" and DIN 18365 "Flooring work", information sheets and technical information of the TKB, the BEB, the CTA and the BVPF-Bundesverband Parkett & Fußboden-technik must be observed. The customer must be informed about the cleaning and care specifications of the product. Any use that does not conform to the scope of Berger-Seidle's application is considered improper. The improper use and non-compliance with the instructions in this manual is largely the responsibility of the processor and as a result excludes the manufacturer's liability and warranty. Before using the product, the general conditions for use must be checked properly and professionally.

References

The following sections of our information pages are integral parts of this information sheet:

- General information about how to use the Berger-Seidle ELASTICLINE
- Cleaning and maintaining flooring
- Labelling and safety information (safety data sheet)

* If the content of the Technical Data Sheet differs from other printed material, e.g. labels, the current version of the Technical Data Sheet on the homepage is always deemed valid. Printed material is always adapted when reprints are made.